




Model Chess · Design by Jens Juul Eilersen

Arm height: 24" · Arm width: 6" - 11 ¾" · Total depth (frame): 37 ½" and 45 ½" · Seat depth: 19 ¾" and 27 ½" · Seat height: 16 ¼" · Total height (frame): 24"




Sofa
82 ¾" x 37 ½"



Closing section
45 ¼" x 37 ½"



Chaiselong
39 ¼" x 61"



Sofa
90 ½" x 37 ½"



Closing section
53 ¼" x 37 ½" and 45 ¼"



Footstool
31 ½" x 23 ½"



Corner section
37 ½" x 37 ½"



Closing section
57" x 37 ½"



Footstool
39 ¼" x 23 ½"



Corner section
Left 37 ½" x right 45 ¼"



Closing section
65" x 37 ½"



Corner section
Left 45 ¼" x right 37 ½"



Closing section
69" x 37 ½"



Centre section
39 ¼" x 37 ½" and 45 ¼"



Closing section
69" x 45 ¼"



Closing section
41 ¼" x 37 ½"



Closing section
82 ¾" x 37 ½"

Scale 1:100


All overall dimensions correspond to frame sizes.

eilersen[®]
since 1895



Model Chess · Design by Jens Juul Eilersen

Arm height: 24" · Arm width: 6" - 11 ¾" · Total depth (frame): 37 ½" and 45 ½" · Seat depth: 19 ¾" and 27 ½" · Seat height: 16 ¼" · Total height (frame): 24"



Scale 1:100

All overall dimensions correspond to frame sizes.