



Model Control · Design by Jens Juul Eilersen

Back height (3 steps): 17 ¼" - 41 ¼" · Foot Support (2 steps): 9" - 16 ½" · Seat height: 15 ¼"



Easy chair  
33 ½" x 71 ¾"



Easy chair  
33 ½" x 71 ¾"